

K1.03 LAZIO TAUPE

PLAINS

KER FINISH



CAUTIONARY NOTES AND CLEANING TIPS

EVERYDAY CLEANING

To clean your KompacPanel surface, a quick wipe-down using a clean cloth or sponge with a mild soap or detergent will do the job. Rinse the surface thoroughly with warm water and wipe dry after.

TREATING STAINS

Treat spills and stains using a mild household cleaner or detergent and a soft bristled brush.

For tough stains, use a paste of baking soda and water and apply with a soft bristled brush. Avoid excessive or forceful scrubbing to prevent damage onto the surface.

For stubborn stains, apply nail polish remover and let it stand for no more than two minutes. Rinse the surface thoroughly with warm water and wipe dry. Repeat only if colour of surface is not affected.

CAUTIONARY NOTES

Avoid direct contact of heat with countertops. Always use a heat shield or pad when using hot pans and heat-producing appliances. Extreme heat can cause cracking and blistering.

Avoid contact with harsh chemicals. In the event of contact, wipe immediately and rinse several times with warm or soapy water.

Avoid using acidic, harsh or abrasive cleaning solutions and tools.

Avoid water ponding on the top surface at all times.

Prolonged exposure of the KompacPanel surface to bleach will cause discolouration.

Do not place KompacPanels outdoors or in places with direct sunlight. UV lighting may affect the colour and shade of the panels over time.



ORIGIN OF DIRT

RECOMMENDED CLEANING PRODUCT AND METHOD

Fruit Juice, Liquor, Milk, Tea, Coffee, Jam, Wines and Spirits

Wash using soft sponge with water.

Animal and Crop Fats, Sauces, Dry Blood, Eggs

Wash with hot water and soap, rinse well and dry with cotton cloth.

Smoke Black, Jelly, Vinyl Adhesives, Watercolour Paints, Organic Residues

Wash with hot water and soap, rinse well and dry with cotton cloth.

Vegetable Oils, Markers, Wax, Residual Solvent Marks

Clean using a cotton cloth with alcohol or acetone, rinse well with cold water and dry.

Linseed Oil

Remove using cotton cloth with acetone.

Neoprene Adhesives

Remove using cotton cloth with thinner.

Synthetic Oil Paints

Remove using cotton cloth with thinner.

Silicon Traces of Residues

Remove gently using wooden or plastic scraper.

Limescale

Remove using detergent with low content of citric or acetic acid, maximum of 10% only.

DISCLAIMER

The KompacPlus Care Guide generally aims to give knowledge on technical aspects of maintaining KompacPanels. This guide in no way accounts for any form of warranty or representations, either expressed or implied, of its fitness and/or the processes required for any specific purposes. Moreover, KompacPlus shall not be held liable for any damages as a result of relying upon this care guide. The KompacPlus product suitability in the user's design and application must be verified and corroborated by the user and relevant professionals. KompacPlus reserves the right to make any amendments and changes to this care guide, whether it be on the product designs and/or descriptions at any time. The copyright of this care guide belongs to KompacPlus and its manufacturers.



UNDERSTAND KOMPACPANELS BETTER

Download a copy of our KompacPlus Care Guide from our website.

A LITTLE CARE
GOES A LONG WAY